Instructions for Use

Key Cable Lock

CODi®
www.codidirect.com

LIMITED LIFETIME WARRANTY

CODi offers a limited lifetime warranty to the original purchaser that its products are free from defects in material and workmanship. If, after inspection, you discover any defects in material or workmanship, CODi will have the option to repair, or, replace the defective CODi product free of charge. This limited lifetime warranty does not cover damages from normal wear and tear or from accidental damage, misuse, improper care, alterations, and damage caused in transportation by a common carrier or airline.

Under no condition is CODi responsible for the following: normal wear and tear; loss or damage to a computer; loss or damage to peripherals; loss or damage to programs; loss or damage to files, records, or data; loss or damage to income.

There are no othe warranties expressed or implied, including, but not limited to, the implied warranties of merchantability and the fitness for a particular purpose beyond the terms of this limited warranty. The limited lifetime warranty offered by CODi herein may not be modified by any oral representations made by any employee, agent, or representative of CODi. This limited waranty gives you, the original purchaser, specific leghts and you may have other rights, which very from state to state.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXLCUSIVE REMEDY OF THE CONSUMER. CODi SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEZUENTIAL DAMAGES FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPICABLE LAW, IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

ADJUSTABLE LOOP KEY CABLE LOCK USER MANUAL

Applications:Briefcase; Luggage; Carrying case; Tool box; LED monitor; Projector; Laptop computer(with handle); printer; copier, and other valuable items.



(Picture 1)



(Picture 2)



(Picture3)

(Picture 4)



(Picture 5)



(Picture 6)



(Picture 7)

Instructions:

1.Loop the cable around any immovable object (picture 1), or use a lock anchor, (picture 2).

2.Insert the non-looped end of cable through the round hole on the lock body, (picture 3), then pull the cable through the round hole and around your object. Once a loop is created around your object, insert the metal piece at the end of the cable into the rectangle slot (as picture 4), push the button to complete the locking process.

3.To lock an object without a handle or through-hole, i.e. a LED flat panel monitor, follow the above two steps but loop the cable end around the monitor's arm (picture 5); slide the lock head up the cable unit till the loop is tight. Find the enclosed break-off screw to tighten it until the screw head snaps. The cable loop diameter will then be fixed in that position (picture 6)

4.You can only use the break off screw once, please make sure you have a tight locking position before using this feature.

5.The break-off screw is an optional accessory. You may choose not to use to fix the cable loop into a locked position.(picture 7)